

TWISTED

A STEAMPUNK SKIRMISH GAME

TERRAIN

No. 42 Carver Lane

Designed and manufactured
in Australia by:

**MINIATURE
SCENERY**

www.miniaturescenery.com



Instructions

www.dementedgames.com





INSTRUCTIONS

No. 42 CARVER LANE

Preparation

Once you clear some table space you will need a hobby knife and glue (PVA, wood glue, hobby glue) and a file or small piece of sandpaper to be used for cleaning up any tiny imperfections.

It's a good idea to familiarise yourself with how the pieces fit together before gluing.

Getting Started

I. Parts should remove easily from the board by pressing through and popping them out. It's a good idea to cut through the tiny joins first though, and some parts (particularly smaller, more detailed parts) may need more careful persuasion.


II. Use a file or sand paper last to completely remove the tabs that might remain.



III. Parts may be a very tight fit, slight trimming or sanding of parts may be needed for ease of assembly.


Construction

Slot the parts together as shown by the pictures below, applying glue wherever there is a connection.


Allow the model to completely dry before painting it. This may be a complex kit with many small parts. Allowing each section to dry thoroughly before heading to the next is strongly recommended.











THESE PARTS
WILL BE VERY
TIGHT. THIS IS
ON PURPOSE SO
YOU WON'T
NEED TO
CLAMP OR TAPE
THE ASSEMBLY.







THE BASIC VERSION
OF CARVER LANE
WILL NOT HAVE
THESE CUT-OUTS IN
THE ROOF PARTS.
























THE FOLLOWING PAGES
CONTAIN EXTRA INSTRUCTIONS
FOR THE CARVER LANE DELUXE
KIT.

